Axelent Product Information

» X-Guard® X-Key



X-Guard[®] X-Key

X-Guard is a complete machine guard series that complies with the amended Machinery Directive 2006/42/EC on fixed guards that came into force on 29 December 2009.

With its wide range of standard components and accessories, X-guard is guaranteed to cover all your machine guard needs. Ever since X-guard was launched it has been under constant development to meet market need for smart solutions that comply with current directives and requirements.

X-Key is an unique tool for quick panel release. Forget about other tools. All you need is X-Key. X-Guard panels can only be removed with the X-Key which offers quick release and replacement.

Two types of X-Key are available. Article **T00-00-IN** with red grip is standard and is included in all panel and post orders. It is intended for removal of panels from inside the hazard zone. This is also the setup recommended by Axelent, because it ensures that the respective machinery is stopped upon opening an interlocked movable guard. Fixed guards can then only be removed under safe conditions.

However, if specifically required for particular maintenance jobs or because of space restrictions, removal of panels is also possible from outside the guarded area. Accessory parts are required to install X-Guard for this type of access. See article **T01-11**. Upon delivery X-Key article **T00-00-EX** is included, with yellow grip intended for this purpose.

X-Key

- Unique tool designed for an intended purpose. See EN ISO 14120: 2015, clause 3.7, 3.8, 5.3.9
- Included in all deliveries



Axelent Product Information

» X-Guard® X-Key

Technical data	
Art.no.	Description
T00-00-IN	X-Key 4.0 for inside release RAL 3001 Signal Red
T00-00-EX	X-Key 4.0 for external release RAL 1018 Zinc Yellow



www.axelent.com

