» Axelent X-It



Axelent X-It cylinder lock

X-It cylinder lock is patented and available in several versions. Thanks to the unique design, no additional lock housing is required; just add a standard profile cylinder such as Euro. The lock is robust with a metal cover to withstand tough conditions and is tested and approved to EN 12209:2016.

The Lock is primarily designed for our modular mesh panel systems for machine guarding, industry and warehouses. The lock can also be used for similar third-party products/systems on the market. Assembly is easy; it is available for both hinge- and sliding doors in right and left versions.

- Available in several versions
- Robust design
- Unique locking function
- Patended product
- Convenient
- Flexible, fits both hinge and sliding doors
- Ordered in right or left execution

- Simple assembly
- Certified product
- Tested and approved to EN 12209:2016
- Possibility to prevent unintended closing during service and maintenance by use of a padlock
- Additional bail handle for use from inside is optionally available
- Supplied in a specially designed box



» Axelent X-It cylinder lock



X-It Cylinder lock		
	Art.no	Description
	XIT-L01-101	X-It Cylinder lock, hinge door, LH
	XIT-L01-301	X-It Cylinder lock, sliding door, left
	XIT-L01-401	X-It Cylinder lock, sliding door with center lock, LH
	XIT-R01-101	X-It Cylinder lock, hinge door, RH
	XIT-R01-301	X-It Cylinder lock, sliding door, RH
	XIT-R01-401	X-It Cylinder lock, sliding door with center lock, RH













Hinge door, right

Hinge door, left S

Sliding door, right

Sliding door, left

Double hinge door left/right





» Axelent X-It cylinder lock with escape release function



In some environments an escape release function may be needed to allow people to leave a locked area from the inside. This may be required if hazards may inadvertently come up or if people could be locked in unintentionally, e.g., in an automatic warehouse. When a lock of this type is installed in the door, it will always be possible to open the door from the inside without a key, even if the lock is in "locked" position. The function upon closing of the door is "slam & shut"; that is, the lock will change to the locked position when you slam the door, even if the key is not in the cylinder of the lock.

Can be used as a door in rail dependent storage and retrieval equipment to EN 528, section 5.9.2.2 b) (4.10.4.2 b) in the 2019 prEN version).

May also be used as a mechanical guard locking device with escape release function to EN ISO 14119 3.27 and 5.7.5.2.

X-It Slam and Shut		
Art.no	Description	
XIT-L14-101	X-It "Slam Shut", esc.rel.function, hinge door, LH	
XIT-L14-301	X-It "Slam Shut", esc.rel.function, sliding door, LH	
XIT-L14-401	X-It "Slam Shut", esc.rel.function, sliding door center lock, LH,	
XIT-R14-101	X-It "Slam Shut", escape release function, hinge door, RH	
XIT-R14-301	X-It "Slam Shut", escape release function, sliding door, RH	
XIT-R14-401	X-It "Slam Shut", esc.rel.function, sliding door center lock, RH	













Hinge door, right

Hinge door, left S

Sliding door, right

Sliding door, left

Double hinge door left/right Sliding door with centrelock, left/right



» Axelent X-It Electric



Can be used in various places within warehouse and production environments, preferable in relation to already installed access systems.

In case of power failure the lock has an escape release function on the inside.

- Light to indicate open or locked
- Cylinder lock with mechanical key that overrides the electronic • function
- Compatible with most electric access lock systems such as • RFID, card readers, Pin code units etc.
- ٠ Storage temperature: -25 to +70 °C according to IEC 60068-2-14
- Operating temperature: -10 to +70 °C according to IEC 60068-2-14 •
- Housing IP rating:
- IP41 Supply voltage: • 12-24 VDC +/-10 % (regulated)

X-It Electric

Art.no	Description	
XIT-L09-101	X-It Electric, esc.rel.function, hinge door, LH	
XIT-L09-301	X-It Electric, esc.rel.function, sliding door, LH	
XIT-L09-401	X-It "Slam Shut", esc.rel.function, sliding door center lock, LH	
XIT-R09-101	X-It Electric, esc.rel.function, hinge door, RH	
XIT-R09-301	X-It Electric, esc.rel.function, sliding door, RH	
XIT-R09-401	X-It Electric, esc.rel.function, sliding door center lock, RH	













Hinge door, right

Hinge door, left

Sliding door, right

Sliding door, left

Double hinge door left/right

Sliding door with centrelock, left/right



» Axelent X-It lock with cylinder

Axelent X-It Cylinder





Axelent X-It Cylinder with escape release function





Axelent X-It Electric





Axelent X-It Eurocylinder Whole (Both sides) / Half (One side)



