Habasit – Solutions in motion



## Granite Big Slabs Polishing Machine Belts NAS-40EHAV-S2 and NAS-50EHAV-S2





Main advantages:

- Perfect adhesion to processed products
- No slab rotation
- High elongation resistance
- Great for uneven surfaces
- Perfect transversal flatness
- Long life

The new hard PVC top cover, with reversed teeth, makes the belts NAS-40EHAV-S2 and NAS-50EHAV-S2, the best solution on the market. The perfect adhesion between the belt and the uneven granite surface, that characterizes this type of belts, has no equal among competitors. It ensures a perfect processing also on machines with long distances and high working speed.

## Granite Big Slabs Polishing Machine Belts NAS-40EHAV-S2 and NAS-50EHAV-S2

## **Cross-section**



NAS-40EHAV-H2

- 1 Conveying side: PVC, Double Saw tooth
- 2 Traction layer: PET fabric
- 3 Running side: Polyester (PET), Impregnated fabric



NAS-50EHAV-H2

## Technical key data

1	Conveying side: PVC,	Double Saw tooth
	oonvoying blact vo,	

- 2 Traction layer: PET fabric
- 3 Running side: Polyester (PET), Impregnated fabric

Туре	Thickness			diameter				Tensile force for 1% elongation (relaxed)			
	mm	inch		mm	inch	N/mm	lbs/inch	N/mm	lbs/inch	Shore A	
NAS-40EHAV-S2	12.0	0.47	3	300	12	42	240	22	126	50	Anthracite
NAS-50EHAV-S2	14.0	0.55	4	400	16	48	274	26	148	50	Anthracite

Information provided herein does not constitute legal representations or warranties and may change without notice. Please refer to the specifications/ disclaimers provided in the respective product data sheets. For further information choose country selection Habasit Worldwide on:

www.habasit.com

Habasit International AG

CH-4153 Reinach-Basel Phone: +41 61 715 15 15 Fax: +41 61 715 15 55 Copyright Habasit AG Subject to alterations

2191FLY.SMC-en0118HQR