Habasit – Solutions in motion



# Habasit soft separator belt



The separator belt is used for desinewing and meat recovery of red meat, pork, poultry, and seafood.

In a "press-separation process," the separator belt presses the soft and hard components against a perforated drum, squeezing the soft components through the holes of the drum, while bone and other hard components remain outside the drum.

This belt's aggressive profile structure promotes high yields, and durable reinforced urethane reduces belt stretch for longer belt life.

### Specifications

- Thermoset urethane EU/FDA compliant
- Polyester reinforcement cord
- Hardness: 85 Shore A
- Color: natural

Habasit Soft Separator Belt				
Habasit Code	Example machine sizes	Dimensions		
		Length [mm]	Width [mm]	Available thickness [mm]
SB-E-1550-205-13-WB-85N-EU	Baader <sup>⊗</sup> 601	1550	205	13.50
SB-E-2390-260-16-WB-85N-EU	Baader® 695/699 and Sepamatic® 2000	2390	260	15.75
SB-E-2820-260-16-WB-85N-EU	Baader® 605/607 and Sepamatic® 4000	2820	260	15.75

## Solutions in motion





Profit from the best consulting and technical support in the lightweight belting industry. Local experts are always available to assist you with your belting needs. The Habasit team is proud to provide the highest level of support, together with top-quality products that have led the global market for decades.

#### Belt selection and calculation assistance

We are always glad to help you select the most suitable belt for any application for your convenience. We now also provide the free online tool 'SeleCalc' which allows you to easily make selections and calculations yourself. Simply register online at selecalc.habasit.com.

#### Fabrication, assembly and local installation services

As a full-service belting provider, we offer joining and assembly services either at our own locations or directly on your equipment.

Habasit has over 30 affiliates worldwide, each with its own inventory, fabrication, assembly and service facilities.

Together with representative offices and numerous qualified distributors, we can react quickly and efficiently to meet all your needs.

#### Customer training programs

To ensure the optimal performance and maximum lifespan of all our products, we offer training programs and various support tools. This includes proper procedures for fabrication, installation, assembly, maintenance and belt repair, all of which take place at a Habasit site or at your location.

#### Belt monitoring, inspections, analyses and process optimization proposals

We organize and handle belt maintenance, inspections, analyses and surveys at customers' sites. Upon request, we are ready to develop optimization proposals to ensure you're getting maximum value from your machinery and process output.



#### Design assistance for customized solutions

Habasit believes in building partnerships with our customers. Our engineering team will work closely with your engineers on joint design developments from initial design to final implementation. This expert service can be invaluable for projects involving new technologies or large-scale modifications and adaptations.

Information provided herein does not constitute legal representations or warranties and may change without notice. Please refer to the specifications/ disclaimers provided in the respective product data sheets. For further information choose country selection Habasit Worldwide on:

www.habasit.com

Habasit International AG

CH-4153 Reinach-Basel Phone: +41 61 715 15 15 Fax: +41 61 715 15 55 Copyright Habasit AG Subject to alterations

4401FLY.CVB-en0819POL