

Axelent X-Tray for X-Guard

Smart cable management for machine guards

Version 3.0 English SE





The finishing touch to your machine safety with X-Tray[®]

Our cable trays are strong, adaptable and easy to fit. They enable elegant solutions with no special tools required. As with X-Guard, only a few brackets and tools are needed. The combination of X-Tray and X-Guard gives you maximum use of minimum material. A simple but smart touch. The near endless possibilities, despite fewer components, saves you time and money through having everything in one order to complete projects.

The perfect fit

No special tools required

The combination is easy to assemble without the need for special tools. A 13 mm spanner is all you require.

One supplier

the same shipment.

Keyhole mounting

Top mounting **Cantilever mounting**



X-Tray cable trays fit our X-Guard machine guard like a glove. Together they provide the optimal solution.

Axelent's X-Tray is the ideal cable tray for X-Guard machine guard because they are perfectly matched for smooth installation to give a professional touch.

A turnkey solution from one supplier makes project implementation that much quicker and easier. It is also cost-effective because everything is bundled in



SnapperWorks software gives you immediate control of your cables

SnapperWorks pairs X-Tray cable trays with X-Guard machine guards, giving you immediate control of your cables.

Benefits of X-Tray for X-Guard

- Cost-effective
- Quick fittings designed for machine guards
- Black galvanized for a perfect match with X-Guard (other colours available)
- Several cable routing options
- All bundled and delivered on the same pallet
- Timesaving quick start-up of machine and production thanks to same pallet shipment (quick and easy installation)

Benefits of SnapperWorks

- Custom program for X-Guard and X-Tray
- Easy to learn, just click and drag
- Provides a complete drawing and a list of materials in no time at all
- DWG and DXF files can be imported

Tested and approved

- X-Tray complies with the highest demands on cable routing systems in accordance with IEC 61537
- X-Tray is a complete cable tray system and is available in a larger range in:
- Zinc Plated FZB
- Hot Dip Galvanized FZV
- Stainless 304L
- Acid-proof 316L





Which cable tray?

What to consider when choosing cable trays

Environment



Environmental requirements for surface treatment and/or classification of installation are based on standards, use, surroundings and specified requirements.

Weight/volume



Weight and volume of the cables taking into account future needs.

Extra weight



Extra weight from point loads.

Installation



Installations in keyholes, at the top of the post, using cantilevers or other methods.

Fixing distance



A greater distance between the fixings means less work and lower costs. We recommend a support distance of 2.25 metres or, together with X-Guard, adapted to the post distances.

Equipotential bonding



Tested for equipotential bonding.



Items • X-Tray for X-Guard • Black

Items • X-Tray for X-Guard • Black





9

Items • X-Tray for X-Guard	I • Black	
X10 Mini Bracket Item No. 2710-2 To mount cable trays on the X14 Pendant, a wall, a machine or similar. Suitable for 60 cm cable trays.	X11 Pendant 240/480 mm Item No. 2711-240 Item No. 2711-480 To mount cable trays with the help of the X10 Bracket or the X15 Cantilever.	L X14 Pendant 280 mm Item No. 2714-280 Used with the X10 Mini Bracket or to fix cable trays to a floor (L1).
X68 Equipotential Bonding Screw Item No. 2568 For equipotential bonding/functional bonding.	Kitter Kitter Kitter Kitter <td< td=""><td>Kan be and the part of the part of</td></td<>	Kan be and the part of
G X65 Tray Cover L=1000 mm Item No. 2765-Wide Length 1000 mm. Width 60, 120, 220, 320 and 420 cm. The cap protects the cables from welding sparks and falling items (G3).	K Vertical Connector Item No. 7700-111 For connecting vertical and horizontal cable trays (K5-7).	X72 Safety Cap 100-pack Item No. 2572-Diameter For 4, 5 and 6 mm wire. Ø 4X-Tray Width 60 Ø 5X-Tray Width 120, 220, 320 Ø 6X-Tray Width 420
A, B, F A, B, F B Self-drilling screws	X75 Bolt Cutter Item No. 2575 Strong bolt cutter with an angled head for easy access.	X76 13 mm Spanner Item No. 2576 We only use M8 carriage bolts so this is the only spanner you require.
Item No. 7100-070 For mounting certain fittings. Surface finish FZB. Included in 7700-015, 7700-065 and 7700-066. Knurled Locking Plug Item No. 7500-191 Included to fix Post Bracket Top (7700-015) and the Top Corner Bracket (7700-066) at the top of the post (B1-2). Plastic.	G Cable Bridge 1200 mm Item No. 279.21.784 – Black Item No. 279.28.720 – Yellow Rubber. Withstands the weight of a truck or Iorry. 210x65x1200 mm. 3 cable channels, 2x20 mm and 1x45 mm (G4).	X77 Wire Cutting Machine K77 Wire Cutting Machine Item No. 2577 Unique and fast wire cutting machine that offers completely grade-free cutting of wire up to 6 mm. Made by Klauke with a guarantee of 10,000 cuts. Bag, battery and charger included.

Art. No	Description
0701-2300	X-Tray 60x60 L=2300 mm / Black Zinc
0711-2300	X-Tray 120x60 L=2300 mm / Black Zinc
0721-2300	X-Tray 220x60 L=2300 mm / Black Zinc
0731-2300	X-Tray 320x60 L=2300 mm / Black Zinc
0741-2300	X-Tray 420x60 L=2300 mm / Black Zinc
1722-2300	X-Tray G120x150 L=2300 mm / Black Zinc
1752-2300	X-Tray Mini 30x22 L=2300 mm / Black Zinc
1752-1200	X-Tray Mini 30x22 L=1200 mm / Black Zinc
2568	X68 Equipotential Bonding Screw / Brass
2572-4	X72 Safety Cap 4 mm (100 pcs)
2572-5	X72 Safety Cap 5 mm (100 pcs)
2572-6	X72 Safety Cap 6 mm (100 pcs)
2575	X75 Bolt Cutter
2576	X76 13 mm Spanner
2577	X77 Wire Cutting Machine, Battery powered
2701	X1 Fitting / Black Zinc
2702	X2 Fitting / Black Zinc
2703	X3 Angled Fitting / Black Zinc
2704	X4 Fitting / Black Zinc
2705	X5 Joining Fitting (20 pcs) incl. bolt & nut / Black Zinc
2761	X61 Bolt M8x27 (40 pcs) / Black Zinc
2762	X62 Flange Nut M8 (40 pcs) / Black Zinc
2710-1	X10 Bracket / Black Zinc
2710-2	X10 Mini Bracket / Black Zinc
2711-240	X11 Pendant Premium 240 / Black Zinc
2711-480	X11 Pendant Premium 480 / Black Zinc
2714-280	X14 Pendant 280 / Black Zinc
2715-120	X15 Cantilever 60 -120 / Black Zinc
2715-220	X15 Cantilever 220 / Black Zinc
2715-320	X15 Cantilever 320 / Black Zinc
2715-420	X15 Cantilever 420 / Black Zinc
2763-1	X63 Accessories Holder / Black Zinc
2765-60	X65 X-Tray Cover 60x1000 mm / RAL 9011 Black
2765-120	X65 X-Tray Cover 120x1000 mm / RAL 9011 Black
2765-220	X65 X-Tray Cover 220x1000 mm / RAL 9011 Black
2765-320	X65 X-Tray Cover 320x1000 mm / RAL 9011 Black
2765-420	X65 X-Tray Cover 420x1000 mm / RAL 9011 Black
2780-1	X80 Side Accessories Holder Black Zinc
279.28.720	Cable Bridge, small Yellow
279.21.784	Cable Bridge, small Black
7100-070	Self Drilling Screw, washer head 4.2x19 / Zinc Plated
7500-191	Knurled Locking Plug
7700-014	Post Bracket X-Guard / Black Zinc
7700-015	Post Bracket Top / Black Zinc
7700-065 *	Corner Bracket X-Guard / Black Zinc
7700-066 *	Top Corner Bracket X-Guard / Black Zinc
7700-032	Cantilever Holder 50x50 X-Guard / Black Zinc
7700-032-2	Cantilever Holder High 50x50 X-Guard / Black Zinc
7700-037	Cantilever Holder Aluminum Rail X-Guard / Black Zinc
7700-060	Adjustable Post Fitting X-Guard / Black Zinc
7700-072	Adjustable Corner Post Fitting X-Guard / Black Zinc
7700-083	Post Cantilever Holder X-Guard / Black Zinc
7700-084	Mesh Panel Mini Bracket X-Guard / Black Zinc
7700-090	Mesh Panel Bracket X-Guard / Black Zinc
7700-111	Vertical Connector Black Zinc
7700-188	Cantilever Holder 70x70 X-Guard / Black Zinc
7700-188-2	Cantilever Holder High 70x70 X-Guard / Black Zinc
9307	X-Tray Demokit X-Guard / Black Zinc

* Only Corner Bracket, not Post Bracket. (Post Bracket 7700-014 purchased separately, previously packed together.)

Order demokit You can also order a demokit of cable trays, brackets and fittings for X-Guard (Item No. 9307). X-Tray comes in a large range. If there is anything you cannot find, please ask us. Most items can be black galvanized with a few weeks delivery date even special colours are available, such as Zinc Plated if your machine is lighter than black.



* These items come with the fittings.

C - Cantilever mounting



D1 60-420



E - Mesh panel mounting



* Horizontal/Vertical

F - Free positioning screw









Assembly Instructions

- Always bolt from inside

H, I, J - Joining/Shaping





H2







x2 2705





x1 2702



x2 2701

x3 2705







x1 x2 x2 2703 2762 2761



